



**Notes:**

The USB cable should be a Micro-B to Type 'A' with the type 'A' end removed and the momentary buttons soldered on to a prototype board connected to the pigtail end of the cable with appropriate strain relief. The type B "micro" end of the cable plugs into the monitor USB port.

The buttons are both normally open, momentary tactile buttons.

<h2>External Button</h2>	
TITLE: external_button	
Document Number:	REV: <b>1.0</b>
Date: 12/14/16 1:04 PM	Sheet: 1/1